




LUTRON



Test



Flashing lens indicator "Low battery"

Auto-On	Activity	Timeout	
Enabled	✓	30 min	•
Low Light	⚡	15 min	•
Disabled	✗	5 min	•

Change settings:
• Hold buttons until LED blinks
• Press button to choose setting
• Hold buttons until LED turns solid