


TX-D4A421 User Guide

Model No. : TX-D4A421
Frequency : 433.92MHz
Operate Voltage : 6V (CR2016*2)
Operate Current : 6mA



Button VS. data table

| Button | | | | Data code | | | |
|-------------|-------------|-------------|-------------|-----------------|----------|----------|----------|
| | | | | D3 | D2 | D1 | D0 |
| Put off | Put off | Put off | Put off | No transmission | | | |
| Push | Put off | Put off | Put off | 0 | 0 | 0 | 1 |
| Put off | Push | Put off | Put off | 0 | 0 | 1 | 0 |
| Put off | Put off | Push | Put off | 0 | 1 | 0 | 0 |
| Put off | Put off | Put off | Push | 1 | 0 | 0 | 0 |

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

To comply with the FCC RF exposure compliance requirements, this device and its antenna must not be co-located or operating to conjunction with any other antenna or transmitter.