

- Locate receiver far away from any metal surface or area, especially do not place it in the iron drawer as it may cause bad signal reception.
- The antenna must be kept in completely vertical extension, otherwise it won't function properly.
- Please adjust the amplifier volume to min. position to avoid damaging the speaker, while installing or connecting any wire.
- After completing installation, first turn on the receiver power for amplifier system (DO NOT switch the microphone on). If there is noise (as LED of CH1 or CH2 is on), check and adjust rear SQ switch till the LED off, then the noise will disappear immediately. If not, there must be a strong interference around the area, Please exchange it and operate with other frequencies.
- When using collar clip mic, please lower the Treble & Bass to prevent the howling caused easily by a by a very close distance to the receiver, due to its high sensitivity and high impedance characteristic.