

## 74501 Operation Descriptions

The battery supplies power to the circuit. The battery voltage is 12V. After simultaneously presses down the keystroke one and the keystroke two 5 seconds, the green light bright, the transmitter starts to work. Presses down the keystroke one or the keystroke two, the red light bright, the transmitter will enter into transmit. When the battery voltage weakens to 9V, after simultaneously presses down the keystroke one and the keystroke two 5 seconds, the green light glittering, the transmitter starts to work. Presses down the keystroke one or the keystroke two, the red light glittering, the transmitter will enter into transmit. After you stop pressing the keystroke for 2 minutes 15 seconds, the transmitter closes down.