

VX-450 Series Type Variation

VX-451-G6-5



VX-454-G6-5



VX-459-G6-5



Front view with antenna



Front view without antenna



Rear view without antenna



Rear view without Battery



Right side



Left side



Top View



Bottom View



Battery Pack FNB-V113LI (2400 mAh) and FNB-V112LI (1170 mAh)



Battery Pack FNB-V113LI (2400 mAh) and FNB-V112LI (1170 mAh)



Battery Charger



AC Adapter



Speaker/Microphone MH-45B4B



Speaker/Microphone MH-360S



Speaker/Microphone MH-450S





VOX Headset VC-25



Antenna



Belt Clip Installation on Battery



View of Belt Clip (Back)

