

CHANNELIZATION of GX2350S(AA1S1/AB1S1) (USA)

No.	Display	TX Frequency	RX Frequency	S/D	Low Po.	Notice *
1	01A	156.050	156.050	S	----	
2	02	-----	-----		----	
3	03A	156.150	156.150	S	----	Bold Channel
4	04	-----	-----		----	
5	05A	156.250	156.250	S	----	
6	06	156.300	156.300	S	----	
7	07A	156.350	156.350	S	----	
8	08	156.400	156.400	S	----	
9	09	156.450	156.450	S	----	
10	10	156.500	156.500	S	----	
11	11	156.550	156.550	S	----	
12	12	156.600	156.600	S	----	
13	13	156.650	156.650	S	LOW	Power Up Mode
14	14	156.700	156.700	S	----	
15	15	-----	156.750		----	RX Only
16	16	156.800	156.800	S	----	
17	17	156.850	156.850	S	LOW	
18	18A	156.900	156.900	S	----	
19	19A	156.950	156.950	S	----	
20	20A	157.000	157.000	S	----	
21	21A	157.050	157.050	S	----	Bold Channel
22	22A	157.100	157.100	S	----	
23	23A	157.150	157.150	S	----	Bold Channel
24	24	157.200	161.800	D	----	
25	25	157.250	161.850	D	----	
26	26	157.300	161.900	D	----	
27	27	157.350	161.950	D	----	
28	28	157.400	162.000	D	----	
29	60	-----	-----		----	
30	61A	156.075	156.075	S	----	Bold Channel
31	62	-----	-----		----	
32	63A	156.175	156.175	S	----	
33	64A	156.225	156.225	S	----	Bold Channel
34	65A	156.275	156.275	S	----	

