Darfon Electronics Corp.

Wireless Keyboard

F8E830-KBD, K105

User Manual

System Requirement

- Win 98, Win 2000, ME or Win XP Operating System
- IBM PC or compatible
- Available PS2 or USB port
- CD-ROM or DVD-ROM drive

Hardware Installation

1. Connecting the receiver module

For USB Interface (If no PS/2 Port)

- Plug the receiver cable into the USB port of your system.
- System will automatically detect for new hardware.
- Follow system instruction for setup

For PS/2 (If no USB port)

- Connect the PS/2 adaptor to the USB connector of the receiver, and plug into the mouse PS/2 port.
- Connect the PS/2 cable (blue) to the keyboard PS/2 port.
- Restart your system.



2. Load batteries in RF keyboard (2 AA batteries for keyboard)


3. Synchronizing the receiver and wireless keyboard

- A. Press the connect button on top of the receiver, then press the button on the bottom of keyboard within 10 seconds.
- B. If the keyboard did not connect, please repeat step A again.

Software Installation

- Insert CD Driver into CD-ROM or DVD drive.
- The system should run automatically; if not, double click "setup.exe"
- The onscreen setup will guide you through rest of the process.
- After the software installation is completed, you will be prompted to restart your computer.

Keyboard Hotkey Definition



Hotkey definition (From Left to Right)

Item	Function	Description
1	Home/Favorite	WWW application
2	Email	Email application
3	Search	Launch the search function of your browser
4	My Document	Open a new document
5	Desktop	Show "Desktop"
6	Calendar	Launch the calendar application
7	F-Lock	Function lock: Enhanced function keys for F1 to F12. Enables key functions between commands on the side of keys, and commands on the top of keys.
		When "Fn Lock is" on, the commands on the top of keys will be
		enabled.
8	My Music	Launch "My music" application
9	Media	Launch "Media" application.
10	Forward	Previous Track
11	Backward	Next Track

12	Play/Pause	Play/Pause
13	Stop	Stop
14	Vol+, Vol -,	Volume Up and Volume Down, and Mute
	Mute	

Enhanced Function keys

	Description		
F1	New: Create a new document or file		
F2	Open: Open a document or file		
F3	Save: Save the document or file in the active window		
F4	Close: Close a document or file at in active window		
F5	Print: Print the document contents in the active window		
F6	Undo: Cancel the previous function		
F7	Redo: Cancel the previous undo action		
F8	Help: Open the "Help" function for the active window.		
F9	Reply: Reply to the email in the active window.		
F10	Fwd: Forward the email in the active window		
F11	Send: Send the email in the active window		
F12	Check: Check the spellings in the active window		

Important Information for RF Product

- For optimal performance, place the receiver at least 8 inches (20 cm) away from any electronics devices (ex. computer, monitor, etc.) to avoid interference.
- Do not place receiver on metal surface.
- When you discover others keyboard and mouse interfering with yours, please **Reset** the keyboard and mouse again.
- After installing the driver, Num/Caps/Scroll Lock Functions will show on Screen.
- When you plug in the receiver into PS/2 port, please do make sure your PC is Power Off.
- The mouse uses a fast and sensitive 800 CPI optical sensor. It will move faster than normal optical mouse. Please change moving speed from **mice setting**.

FCC Warning!

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by on or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1)this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation.

The user manual or instruction manual for an intentional or unintentional radiator shall caution the user that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.