

Belkin Bluetooth Wireless Keyboard

Quick Setup Guide

1. Important Health Information

Certain repetitive strain injuries, including pain, numbness and weakness to hands, wrist, arms, neck and/or back have been identified by some experts as being associated with the prolonged use of keyboards. If you are experiencing injury symptoms, consult a medical professional. A person's susceptibility to these injuries may be affected by many factors including body posture, repetitive physical activities and their general physical health.

FCC Warning

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation.

The user manual or instruction manual for an intentional or unintentional radiator shall caution the user that changes or modifications not expressly

approved by the party responsible for compliance could void the user's authority to operate the equipment.

2. Package Contents

Belkin bluetooth wireless keyboard

Belkin USB Dongle/receiver

2 AA alkaline batteries

CD Software with driver

Quick Setup Guide

3. System Requirements:

- IBM® compatible system.
- Microsoft Windows® 98, 2000, Me, XP.
- Available USB port or PS/2 keyboard & mouse port.
- CD-ROM or DVD-ROM drive.
- At least 32MB of RAM and 20MB of available hard-drive space.

To use Internet & Email hotkeys, the system needs to have:


- Internet access.
- Microsoft® Internet Explorer 4.0 or higher, Netscape (Navigator 4.0 or higher, or American Online 5.0 or higher).

To use Media Console functions, the system needs to have

- A sound card and speakers.

4. Hardware Installation


- Turn off your computer



- Load Batteries

Step 1. Load the AA batteries (included) in the bluetooth wireless keyboard.


Step 2. Follow the polarity indicators to load the batteries.



- **Connecting the receiver**


For USB Interface

- Step 1. Connect the USB connector on receiver cable to your computer or to the Hub connected to your computer.
- Step 2. Restart the computer.
- Step 3. System will automatically detect for new hardware.
- Step 4. Follow system's setup instruction.



- **Software Installation (for hotkey functions)**

- Step 1. Insert driver CD into CD-ROM or DVD drive.
- Step 2. The installation program should run automatically. If not, double click "setup.exe"
- Step 3. The onscreen setup will guide you through rest of the installation process.
- Step 4. After the software installation is completed, you will be prompted to restart your computer.











Congratulations!

Your Belkin Bluetooth wireless keyboard is now ready to use.








6.Keyboard Hotkeys Definition

Internet Hotkeys Function

Function	Description
 Home	Launches the home page for the default web browser, can be programmed for another function.
 Favorites	Open "My Favorites" folder, can be programmed for another function.
 Search	Launches the default online search engine website, can be programmed for another function.
 Back	"Previous Page", this key can be programmed for another function.
 Forward	"Next Page", this key can be programmed for another function.
 Stop	Web Stop. Puts the browser into stand mode.
 Refresh	Refresh. Puts the browser into renew page mode.
 Email	Launches the default email program, can be programmed for another function.

Media Hotkeys Function

Function	Description
----------	-------------

 calculator	Calculator. Open Windows application.
 media	Media. Open Windows Multimedia application.
	Backward.
	Forward.
	Play/Pause.
	Volume up.
	Mute key.

7. Trouble Shooting

Keyboard does not work:

- Please make sure the receiver's connectors are plugged correctly into your computer. Before you plug the PS/2 connector on receiver cable into PS/2 port, please do make sure your PC is Power Off.
- Please make sure the batteries are loaded correctly in both the keyboard and mouse.
- Please check battery life
- Please press the connect button on top of the receiver, then press the button on the bottom of the keyboard within 10 seconds. Press the connect button on top of the receiver, then use a sharp point (e.g. the point head of your pen) object to press the connect button on the bottom of the mouse within 10 seconds.
- Reload batteries and repeat wireless connect again.
- When you find your keyboard is experiencing interferences by other wireless input devices, please reset the keyboard again.
- Place the receiver at least 8 inches (20 cm) away from any electronic devices (ex. computer, monitor, etc.) to avoid interference.
- Do not place receiver on metal surface.
- After installing the driver, Num/Caps/Scroll Lock function indicators will be showed on the screen.
- Please refer to the online user manual for more details.

Belkin software does not work:

- Make sure the keyboard is connected and synchronized correctly.
- Make sure the software is installed correctly.
- Uninstall and re-install the software.
- Please refer to the online user manual for more details.

8. Online Keyboard User Manual

- Please refer to your online user manual to get the most out of your keyboard.

To access the online user manual:

- Please install Belkin Bluetooth driver first.
- Move mouse pointer to the Belkin BT driver icon located in the system tray on the lower right corner. Then click the right button of the mouse to display Belkin Bluetooth menu.
- Select "Help" option in the Belkin Bluetooth menu for online user manual.

9. Warranty

Warranty:

- One year parts/labor from purchase date
- Belkin Corp. ("Belkin") warrants Belkin keyboard with accompanying mouse cables and adapters (collectively "keyboard") you have purchased from Belkin or from a Belkin authorized reseller/retailer to be free from defects in materials or workmanship under normal use during the warranty period. Please visit <http://web.belkin.com/claims/claims.asp> for more details.

Registration:

- Please go to <http://www.belkin.com/contactus/registration.html> to register your product.

Contact Information

For warranty & technical support, please call 1-800-2-BELKIN or visit us at <http://web.belkin.com/support/>



Hours: M-F 7:00am - 5:30pm PST

For further product information or rebate questions, please call 310-898-1100 Ext 2263.



Hours: M-F 8:00am - 5:00pm PST

You may also **request information** by mailing to the following address:

Belkin Components
501 West Walnut Street
Compton, CA 90220