

# PROFESSIONAL



**Safe pets. Happy owners.**

**Operation's Manual**  
**Please read and keep for future reference.**

The world leader in electronic pet training and containment systems.

**TABLE OF CONTENTS:**

- I. HOW THE SYSTEM WORKS
- II. FENCE TRANSMITTER COMPONENTS AND FEATURES
- III. RECEIVER WITH COLLAR SET-UP AND OPERATION
- IV. TIPS FROM THE EXPERTS

**What your Pet Containment System IS and IS NOT**

IS a deterrent to train pets to remain within the boundary established.

IS a great training aid.

IS for residential use only.

IS for healthy dogs. If you have doubts, contact your veterinarian.

IS NOT a solid barrier. It will not work without proper training.

IS NOT for use with vicious animals or guard dogs. If you believe your dog may pose a threat to others, **DO NOT USE THIS SYSTEM.**

Radio Systems Corporation shall **NOT** be liable for any property damage, economic loss or any consequential damages sustained as a result of an animal crossing the boundary.

**Caution!**

The danger of explosion exists if the battery is replaced incorrectly. Use only the same or equivalent battery as described in this manual. Take dead batteries to a household hazardous waste collection program in your area or give to a licensed hazardous waste contractor.

**How the system works**

The Pet Containment System consists of three primary components:

**TRANSMITTER, RECEIVER,** and **BOUNDARY WIRE** (antenna). The transmitter is a very low frequency radio transmitter that plugs into a standard outlet. The signal it transmits is carried by the boundary wire which serves as an antenna. The signal it transmits is carried by the boundary wire which serves as an antenna. The range of the signal (i.e. the distance from the boundary wire to activate the receiver) can be adjusted from a few feet up to thirty feet by the range adjustment knob located on the transmitter.

**Professional Fence Transmitter ProTX-1  
Components and Features**



**Receiver Test Station  
Test Light**

**Power Indicators  
On/Off Light**

**Loop Indicators 1 and 2  
Light On - No Problems  
Light Off - Possible Broken Wire**