

8. Configuration photographs

Conducted emission at mains port [H Print, Centronics I/F mode]



The photographs show maximized emission configuration.

Radiated emission [H Print, Centronics I/F mode]



The photographs show maximized emission configuration.

Conducted emission at mains port [H Print, RS232C I/F mode]



The photographs show maximized emission configuration.

Radiated emission [H Print, RS232C I/F mode]



The photographs show maximized emission configuration.

Conducted emission at mains port [H Print, USB /FI mode]



The photographs show maximized emission configuration.

Radiated emission [H Print, USB I/F mode]



The photographs show maximized emission configuration.

Conducted emission at mains port [H Print, LAN I/F mode]



The photographs show maximized emission configuration.

Radiated emission [H Print, LAN I/F mode]



The photographs show maximized emission configuration.