

McMurdo G5 and E5 EPIRBs











ACTIVATION
... see Label Artwork for more detail



Battery Expiry Label - inside dome






Compliance Information
... see Label Artwork for more detail

... to uncover Programming Label:















ACTIVATE switch ... red tab must be torn away to allow operation





## **Automatic Release Housing**





with BreaktHRU HRU





with Hammar HRU

## **Hydrostatic Release Units**









## Manual Release Bracket







