

3. Transmitter (41704, 41706, 41707 and 41337)

3-1. Model Name

Transmitter


3-2. Model Numbers and Difference

Model Number	Freq. (MHz)	Function				Number of button	PWB No.
		LOCK	UNLOCK	TRUNK	PANIC		
41704	315.0	O	O	O		3	41601
41706	315.0	O	O		O	3	As above
41707	315.0	O	O			2	As above
41337	315.0	O	O			2	As above


Note) Same PWB is used for all models.

3-2. Label Art-Work

For USA,CANADA



For other countries



3-10. Appearance

