

1 Annex B – EUT pictures

1.1 List of Pictures

Picture 1: FS14T, version FS14T with test mode - top side.....2
Picture 2: FS14T, version FS14T with test mode - bottom side.....2
Picture 3: FS14T, version FS14T with test mode - top side.....3
Picture 4: FS14T, version FS14T with test mode - bottom side.....3
Picture 5: FS14T, version FS14TK with test mode - top side4
Picture 6: FS14T, version FS14TK with test mode - bottom side4
Picture 7: FS14T, version FS14TK with application mode - top side5
Picture 8: FS14T, version FS14TK with application mode - bottom side.....5



Picture 1: FS14T, version FS14T with test mode - top side



Picture 2: FS14T, version FS14T with test mode - bottom side



Picture 3: FS14T, version FS14T with test mode - top side



Picture 4: FS14T, version FS14T with test mode - bottom side



Picture 5: FS14T, version FS14TK with test mode - top side



Picture 6: FS14T, version FS14TK with test mode - bottom side



Picture 7: FS14T, version FS14TK with application mode - top side



Picture 8: FS14T, version FS14TK with application mode - bottom side