



Connection point of the Print Inverted F antenna





Connect point of the wireless module
It is connected with U.FL cable.