



MODEL SW-08

Set switch to "On" position:

Press and hold the "Push-to-Talk" button to talk, and release it to hear.

How To Use:

Insert 4x9V D03P/6F22 size batteries into the battery compartment.

Beware of the positive and negative sign.

Caution:

- Turn power off when not play
- Batteries are to be inserted with the correct polarity.
- The supply terminals are not to be short-circuited.
- Do not mix old and new batteries, do not mix alkaline, standard carbon zinc or rechargeable nickel cadmium batteries.
- Non-rechargeable batteries are not to be charged.
- Exhausted batteries to be removed from the unit
- Remove batteries when not in use for prolonged periods.
- Packing with instruction to be kept for reference.

MADE IN CHINA



WARNING:
NOT SUITABLE FOR CHILD
UNDER 36 MONTHS DUE
SMALL PARTS



WARNING:

CHOKING HAZARD - small parts
Not for children under 3 years.



Patent Pending & Design Registered

