

Congratulations on your purchase of the Skylink® Wireless keypad Model KN-318. The Model KN-318 works with the Skylink® Smart Button™ or receivers. In this package, you will find a wireless keypad with 1.5V AAA battery and screws.

The keypad transmitter can operate up to 4 Smart Button™ units, that also means one keypad transmitter can operate up to 4 garage door openers.

Same PIN will be used for all doors. The factory default password is [0 0 0 0].

To operate door 1, you will enter [0 0 0 0][#][1]

To operate door 2, you will enter [0 0 0 0][#][2]

To operate door 3, you will enter [0 0 0 0][#][3]

To operate door 4, you will enter [0 0 0 0][#][4]

To program the keypad transmitter into the Smart Button™, you must decide which door you need to operate. If you only have one Smart Button™, we suggest you to use door 1. i.e. [0 0 0 0][#][1]. Follow the instructions below to program the keypad transmitter.

Follow the instructions below to change the PIN.

To change your PIN:

1. Enter the current PIN, (factory default PIN 0 0 0 0), press * .
2. Enter new 4 to 6 digit PIN, press * .
3. Enter new PIN again, press * .

For example, if you are changing the PIN number from 0000 to 123456, enter the following sequence, 0000, *, 123456, *, 123456, * . If confirmed, the backlit LED flashes and the unit emits a long beep.

One 1.5 volt AAA type battery (included).

It is time to change the battery when the backlight no longer appears.

The Wireless keypad is approved by the FCC and it complies with

FCC

This device complies with Part 15 of the FCC Rules and Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme aux Partie 15 des règlements de la FCC et CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

(1) l'appareil ne doit pas produire de brouillage, et

(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

WARNING:

Changes or modifications to this unit not expressly approved by the party responsible of compliance could void the user's authority to operate the equipment.

WARRANTY

If, within one year from date of purchase, this product should become defective (except battery), due to faulty workmanship or materials, it will be repaired or replaced, without charge. Proof of purchase and a Return Authorization Number are required.

CUSTOMER SERVICE

If you would like to

- find out the up-to-date specifications
- know more about features and applications
- download documents, i.e. user's instructions
- order Skylink products

or if you have difficulty getting products to work, please:

1. visit our FAQ section at www.skylinkhome.com, or
2. email us at support@skylinkhome.com

CUSTOMER SERVICE

17 Shread Avenue,

Brampton, Ontario,

Canada L6Y 1J3

Email: sales@skylinkhome.com

<http://www.skylinkhome.com>

©2013 SKYLINK GROUP