

Alert system Model GS-MT FCC ID: KUTWDG10X

1. INTRODUCTION

The garage door sensor model GS-MT is designed to monitor the status of your garage door and advise you if the door is open. By placing the sensor on the door panel, you will be alerted when the door is open. When the garage door is open, the receiver will beep and flash.

In this package, you should find a sensor and mounting accessories.

Please follow the instructions below to setup the garage door sensor.

2. INSTALLATION

- i) Remove the top cover of the sensor and insert one AAA battery (sold separate) to the sensor as shown in the diagram.
- ii) Before inserting the battery, keep the sensor in vertical position. After inserting the battery to the sensor, press and hold the learn button in the receiver unit, release the button when the receiver emits a beep. Select the zone location, press the zone button [1 or 2 or 3 or 4] once on the receiver unit. The corresponding zone red LED on the receiver will flash.
- iii) Tilt the sensor in horizontal position, the receiver unit will emit a long beep indicating it has learned the code from the sensor.

MOUNTING LOCATION

You can mount the sensor onto your garage door with double-sided foam tape if the surface of your garage door is smooth and clean enough to provide a good adhesive surface, such surface can usually be found on a metal garage door. Please ensure the surface is smooth and clean.
Important:

OPERATION

When the sensor is tilt such as when the door is open, the sensor will send a signal to the receiver, and the receiver will beep and the corresponding zone red LED will flash.

FCC

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

WARRANTY

If, within one year from date of purchase, this product should become defective (except battery), due to faulty workmanship or materials, it will be repaired or replaced, without charge. Proof of purchase and a Return Authorization are required.

CUSTOMER SERVICE

If you would like to order Skylink's products or have difficulty getting them to work or download information and user manual, please:

1. visit our FAQ section at www.skylinkhome.com, or
2. email us at support@skylinkhome.com, or
3. call our toll free at 1-800-304-1187 from Monday to Friday, 9 am to 5 pm EST.

17 Sheard Avenue, Brampton, Ontario, Canada L6Y 1J3
©2014 SKYLINK GROUP

