


PC BOARD ASS'Y - TOP, WITH SHIELD




PC BOARD ASS'Y - TOP, NO SHIELD



PC BOARD ASS'Y - TOP WITH BATTERY REMOVED



PC BOARD ASS'Y – BOTTOM



PC BOARD ASS'Y BOTTOM - NO BATTERY, NO SHIELDS



PC BOARD BOTTOM - NO SHIELDS, NO BATTERY