

# **Smart Sense Product Marking**

## **Model Number Identification**

- 1) Print model number on side of transmitter enclosure
- 2) Use Size 14 font
- 3) Printed Information
  - a. Transmitters are labeled with an ink-jet printer, with 2 lines of information centered on side of transmitter enclosure.
  - b. The first line begins with the ID number (#xxx) followed by the Expiration month/year (EXP: xx/xx). The expiration is one year from the date of shipping.
  - c. The second line contains the model number.

## **Model 9450-5066 Smart Sense Transmitter, 66 kHz**



## **Model 9450-5262 Smart Sense Transmitter, 262 kHz**



## **Product Labeling with RFT Web Address (Both models)**

Place product label with RFT web address on top of enclosure



**FCC and IC numbers**

Molded into the underside of transmitter enclosure

