

FCC ID: L2599103



SUPREME TOYS (H.K.) LTD.

INSTRUCTION

ITEM NO. 99103

CAUTION:

1. Your Transceiver Set has been fully adjusted prior to shipment from the factory. Be sure not to touch the internal components other than replacing the battery.
2. When the sound becomes weak, it is time to change the Battery.
3. After use, always return the "ON-OFF" Switch to the "OFF" position.
4. Keep your set in a dry and clean place.

HOW TO OPERATE YOUR TRANSCEIVER:

1. Open battery cover and snap in a 9-volt battery.
2. Turn the "ON-OFF" switch to "ON" position. Your transceiver is now ready to operate.
3. Press the "PUSH-TO-TALK" switch for transmitting.
4. Release the "PUSH-TO-TALK" switch for receiving.
5. When transmitting, speak clearly in a normal voice, holding the set about 3" from your mouth.
6. Best transmission and reception are obtained when the antenna is held in a vertical position.

REMARK:

User Can not modify this product.

Hong Kong Office : Rm 907-9, 9/F Tower B, New Mandarin Plaza, 14 Science Museum Road,
Tsimshatsui East, Kowloon, Hong Kong
Tel: 2317 5168 Fax: 2317 6607 E-mail: SUPREMEH@HKSTAR.COM
USA Office: 8348 C. Olive St. Rd.,
St. Louis, MO 63132, USA.
Tel: (314) 567-1777 Fax: (314) 567-1734 E-mail: IABDROB@AOL.COM