


Wireless Bluetooth Keyboard




Pairing, operating, and charge:


1. You must first pair Bluetooth keyboard with iPad before you can use it.

Follow the below instructions.

Switch the keyboard power on then press pairing button while blue LED sparkling.



● In iPad setting, choose General > Bluetooth, and turn Bluetooth on.



If battery low light, please use the micro USB cable to charge since the light is off.


2. When using, LED indicator will notice the below message.

Blue: Bluetooth pairing status

Red: Battery low indicate

Amber: Charging status

3. If the battery low is light, you must charge the battery using the included Micro USB power cable.



* Before using first time, please charge at least 3 hours while the battery is full.

Keyboard layout:

Some of keys like 'fn', 'f1~f16', 'home' and 'end'... are not defined in iPad, but it is compatible with Apple OS.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.