







4.3.2.4 Portable Mode

4.3.2.4.1 Portable Mode (Playback)





4.3.2.4.2 Semi-Portable Mode (CLA power and headphone)






Figure 36 200MHz to 1GHz Vertical








Figure 37 200MHz to 1GHz Horizontal

4.3.2.5 USB Mode

4.3.2.5.1 USB Mode Receive Data



4.3.2.5.2 USB Mode Transmit Data




Figure 42 30MHz to 200MHz Vertical




Figure 43 30MHz to 200MHz Horizontal




Figure 44 200MHz to 1GHz Vertical




Figure 45 200MHz to 1GHz Horizontal