

***** frequency hoping table *****

base Frequency = 919 Mhz

HOP	FREQUENCY
0	919570000
1	920530000
2	920740000
3	919930000
4	919210000
5	920170000
6	919300000
7	920620000
8	920290000
9	920860000
10	919840000
11	920140000
12	919330000
13	920650000
14	920260000
15	920470000
16	920200000
17	919990000
18	919240000
19	920080000
20	920110000
21	920770000
22	919630000
23	920890000
24	919420000
25	919600000
26	920440000
27	920230000
28	920320000
29	919150000
30	919810000
31	920590000
32	920680000
33	919390000
34	919690000
35	920050000
36	919780000
37	920710000
38	919360000
39	919120000
40	919540000
41	920500000
42	919720000
43	920560000
44	919660000
45	920020000
46	919510000
47	920350000
48	920800000
49	919870000
50	919900000
51	920380000
52	920410000
53	919180000

54	919060000
55	919480000
56	919960000
57	919000000
58	919270000
59	919750000
60	920830000
61	919450000
62	919090000
63	919030000
64	919090000
65	919450000
66	920830000
67	919750000
68	919270000
69	919000000
70	919960000
71	919480000
72	919060000
73	919180000
74	920410000
75	920380000
76	919900000
77	919870000
78	920800000
79	920350000
80	919510000
81	920020000
82	919660000
83	920560000
84	919720000
85	920500000
86	919540000
87	919120000
88	919360000
89	920710000
90	919780000
91	920050000
92	919690000
93	919390000
94	920680000
95	920590000
96	919810000
97	919150000
98	920320000
99	920230000
100	920440000
101	919600000
102	919420000
103	920890000
104	919630000
105	920770000
106	920110000
107	920080000
108	919240000
109	919990000
110	920200000
111	920470000
112	920260000
113	920650000
114	919330000

115		920140000
116		919840000
117		920860000
118		920290000
119		920620000
120		919300000
121		920170000
122		919210000
123		919930000
124		920740000
125		920530000