


APPENDIX C - EUT PHOTOGRAPHS

Base – Top View (Model: GH3150)



Base - Bottom View (Model: GH3150)



Base – Side View (Model: GH3150)



Base – Top View (Model: GH3110 & GH3100)



Base - Bottom View (Model: GH3110 & GH3100)



Power Adapter – Top View

