

1 Annex A - UUT DFS Setup Photographs

1.1 Conducted DFS – AP Mode



1.2 Conducted DFS – P2P, P2MP and Client with Client Detecting Mode



1.3 Conducted DFS –Client with Master Detecting Mode



1.4 Conducted DFS –WGB Mode

