

Internal EUT Photographs

EUT rear cover removed



Inside Front Cover




Inside Back Cover of EUT



Battery Compartment of EUT



EUT Processor Board Component Side



EUT Processor Board: Shields Removed



EUT Processor Board Foil Side

