

This system comprises of an Electronic Control Unit with immobilizer relay to connect to the electrical system and a Steering Wheel Lock with Remote Control. Locking the Steering Wheel Lock will cause the system to mechanically and also electrically immobilize the car. Unlock the Steering Wheel Lock will automatically dis-arm the system.