

1. Normal Mode : When the tire pressure is normal, the transmitter will transmit a 10ms signal in 54.6 seconds time interval for polling the system integrity.
2. Alarm Mode : When 3 PSI tire pressure down is detected, the transmitter will transmit a 10ms signal which contains alarm codes in every 54.6 seconds.