

# **Exhibit E**

# **User's Manual**


**LITE-ON AUTOMOTIVE CORP.**

**FCC ID.:LJLMICROWAVE**

**Microwave Sensor**

# OPERATING MENU

1. When object move to microwave sensor. The LED turn light.
2. VR can adjust its sensitivity.



Notice : The changes or modifications not expressly approved by the party responsible  
For compliance could void the user's authority to operate the equipment