


## 802.11a – Ant 1

## Channel 1 (5955MHz)

## The Reference Level




## The Mask Data



## Channel 49 (6195MHz)

## The Reference Level




## The Mask Data



## Channel 93 (6415MHz)

## The Reference Level




## The Mask Data



802.11a – Ant 1

Channel 97 (6435MHz)

The Reference Level




The Mask Data



Channel 105 (6475MHz)

The Reference Level




The Mask Data



Channel 113 (6515MHz)

The Reference Level




The Mask Data



802.11a – Ant 1

Channel 117 (6535MHz)

The Reference Level




The Mask Data



Channel 149 (6955MHz)

The Reference Level




The Mask Data



Channel 181 (6855MHz)

The Reference Level




The Mask Data



## 802.11a – Ant 1

## Channel 185 (6875MHz)

## The Reference Level




## The Mask Data



## Channel 189 (6895MHz)

## The Reference Level




## The Mask Data



## Channel 209 (6995MHz)

## The Reference Level




## The Mask Data



802.11a – Ant 1

Channel 229 (7095MHz)

The Reference Level



The Mask Data



802.11a – Ant 2

Channel 1 (5955MHz)

The Reference Level




The Mask Data



Channel 49 (6195MHz)

The Reference Level




The Mask Data



Channel 93 (6415MHz)

The Reference Level




The Mask Data



802.11a – Ant 2

Channel 97 (6435MHz)

The Reference Level



The Mask Data



Channel 105 (6475MHz)

The Reference Level




The Mask Data



Channel 113 (6515MHz)

The Reference Level




The Mask Data



## 802.11a – Ant 2

## Channel 117 (6535MHz)

## The Reference Level




## The Mask Data



## Channel 149 (6695MHz)

## The Reference Level




## The Mask Data



## Channel 181 (6855MHz)

## The Reference Level




## The Mask Data



802.11a – Ant 2

Channel 185 (6875MHz)

The Reference Level




The Mask Data



Channel 189 (6895MHz)

The Reference Level




The Mask Data



Channel 209 (6995MHz)

The Reference Level




The Mask Data




802.11a – Ant 2

Channel 229 (7095MHz)

The Reference Level




The Mask Data



802.11a – Ant 3

Channel 1 (5955MHz)

The Reference Level




The Mask Data



Channel 49 (6195MHz)

The Reference Level




The Mask Data



Channel 93 (6415MHz)

The Reference Level




The Mask Data



## 802.11a – Ant 3

## Channel 97 (6435MHz)

## The Reference Level




## The Mask Data



## Channel 105 (6475MHz)

## The Reference Level




## The Mask Data



## Channel 113 (6515MHz)

## The Reference Level




## The Mask Data



802.11a – Ant 3

Channel 117 (6535MHz)

The Reference Level




The Mask Data



Channel 149 (695MHz)

The Reference Level




The Mask Data



Channel 181 (685MHz)

The Reference Level



The Mask Data



## 802.11a – Ant 3

## Channel 185 (6875MHz)

## The Reference Level




## The Mask Data



## Channel 189 (6895MHz)

## The Reference Level




## The Mask Data



## Channel 209 (6995MHz)

## The Reference Level



## The Mask Data



802.11a – Ant 3

Channel 229 (7095MHz)

The Reference Level



The Mask Data

