



802.11ax-HE80 – Ant 1

Channel 7 (5985MHz)

The Reference Level




The Mask Data




Channel 55 (6225MHz)

The Reference Level




The Mask Data




Channel 87 (6385MHz)

The Reference Level




The Mask Data




802.11ax-HE80 – Ant 1

Channel 103 (6465MHz)

The Reference Level




The Mask Data




Channel 119 (6545MHz)

The Reference Level




The Mask Data




Channel 135 (6625MHz)

The Reference Level




The Mask Data




802.11ax-HE80-Ant 1

Channel 151 (6705MHz)

The Reference Level




The Mask Data




Channel 167 (6785MHz)

The Reference Level




The Mask Data




Channel 183 (6865MHz)

The Reference Level




The Mask Data




802.11ax-HE80- Ant 1

Channel 199 (6945MHz)

The Reference Level




The Mask Data




Channel 215 (7025MHz)

The Reference Level




The Mask Data




802.11ax-HE160 – Ant 1

Channel 15 (6025MHz)

The Reference Level




The Mask Data




Channel 47 (6185MHz)

The Reference Level




The Mask Data




Channel 79 (6345MHz)

The Reference Level




The Mask Data




802.11ax-HE160 – Ant 1

Channel 111 (6505MHz)

The Reference Level




The Mask Data




Channel 143 (6665MHz)

The Reference Level




The Mask Data



Channel 175 (6825MHz)

The Reference Level




The Mask Data




802.11ax-HE160 – Ant 1

Channel 207 (6985MHz)

The Reference Level




The Mask Data



802.11be-EHT20 – Ant 1

Channel 1 (5955MHz)

The Reference Level




The Mask Data




Channel 49 (6195MHz)

The Reference Level




The Mask Data




Channel 93 (6415MHz)

The Reference Level




The Mask Data



802.11be-EHT20 – Ant 1

Channel 97 (6435MHz)

The Reference Level




The Mask Data




Channel 105 (6475MHz)

The Reference Level




The Mask Data




Channel 113 (6515MHz)

The Reference Level




The Mask Data



802.11be-EHT20 – Ant 1

Channel 117 (6535MHz)

The Reference Level




The Mask Data



Channel 149 (695MHz)

The Reference Level




The Mask Data



Channel 181 (685MHz)

The Reference Level




The Mask Data




802.11be-EHT20 – Ant 1

Channel 185 (6875MHz)

The Reference Level



The Mask Data




Channel 189 (6895MHz)

The Reference Level




The Mask Data




Channel 209 (6995MHz)

The Reference Level




The Mask Data




802.11be-EHT20 – Ant 1

Channel 229 (7095MHz)

The Reference Level




The Mask Data




802.11be-EHT40 – Ant 1

Channel 3 (5965MHz)

The Reference Level



The Mask Data




Channel 51 (6205MHz)

The Reference Level




The Mask Data




Channel 91 (6405MHz)

The Reference Level




The Mask Data



802.11be-EHT40 – Ant 1

Channel 99 (6445MHz)

The Reference Level




The Mask Data




Channel 107 (6485MHz)

The Reference Level



The Mask Data



Channel 115 (6525MHz)

The Reference Level



The Mask Data




802.11be-EHT40 – Ant 1

Channel 123 (6565MHz)

The Reference Level




The Mask Data




Channel 147 (6685MHz)

The Reference Level




The Mask Data



Channel 179 (6845MHz)

The Reference Level



The Mask Data

