

Removal/Installation Instructions for 5755 Receiver

865575 G397142

Remove the RF receiver (Central control module)

Remove

Disconnect the battery ground cable.

G301325 Remove the RH A-pillar upper trim panel.

G301329 Remove the RH B-pillar upper trim panel.

G301333 Remove the RH C-pillar upper trim panel.

Remove the RH sun visor.

Release the screw cover.

Remove the screws.

Disconnect the electrical connector.

Remove the RH sun visor clip.

Release the screw cover.

Remove the screw.

Remove the RH passenger assist handles.

Carefully release the 4 screw covers.

Remove the 4 screws.

Release the RH side of the headliner.

Carefully release the 4 clips.

Remove the central control module.

Disconnect the 2 electrical connectors.

Remove the 2 bolts.

Install

Install the RF receiver. (CC module)

Connect the electrical connectors.

Tighten the bolts to 10 Nm (7 lb.ft).

Secure the RH side of the headliner.

Carefully secure the clips.

Install the RH passenger assist handles.

Install the screws.

Install the screw covers.

Install the sun visor clip.

Install the screw.

Install the screw cover.

Install the RH sun visor.

Connect the electrical connector.

Install the screws.

Install the screw cover.

G301333 Install the RH C-pillar upper trim panel.

G301329 Install the RH B-pillar upper trim panel.

G301325 Install the LH A-pillar upper trim panel.

Connect the battery ground cable.

Note: This device complies with Part 15 of the FCC Rules and with RSS-210 of Industry Canada.

Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.