

Operation Manual for RMBS Receiver Module

1. Unscrew the terminal screws on the standard wired chime base.
2. Place the Receiver module to match the 4 terminal holes on the standard wired chime base, screw in place.
3. Insert battery on the chime base and match polarity.
4. The wired chime can now worked with the supplied wireless pushbutton.
5. You can place the wired chime within 100 feet from the wireless pushbutton. When the button is pressed, the chime will sound ding-dong.

CAUTION: Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment