

IMPORTANT

1. MODIFICATIONS NOT AUTHORIZED BY THE MANUFACTURER MAY VOID USER'S AUTHORITY TO OPERATE THIS DEVICE.
2. EMISSIONS OR INTERFERENCE OF SURROUNDING ELECTRONIC EQUIPMENT MAY AFFECT OPERATING PERFORMANCE.

CAUTION

1. Not suitable for children under 3 years.
2. Do not use rechargeable batteries for the Remote Control Handset.

NOTE: The voltage of a fully-charged, rechargeable battery is often lower than that of a fresh alkaline battery. Therefore, it is recommended that alkaline batteries be used instead of rechargeable batteries for best performance and for longest play time.

FCC COMPLIANCE

NOTE: This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

[Hereby, MGA Entertainment (H.K.) Ltd, declares that this Bratz™ The Movie RC Cruiser is in compliance with essential requirements and other provisions of Directive 1999/5/EC.]

Please keep this manual as it contains important information.



0307-0

www.bratz.com
TM & © MGA Entertainment, Inc.
BRATZ™, BRATZ PETZ™, LIL' BRATZ™,
BRATZ BABYZ™, BRATZ KIDZ™ and all
related logos, names, characters, distinctive
likenesses and slogans, as well as the
packaging and images appearing thereon, are
the exclusive property of MGA.
16300 Roscoe Blvd.
Van Nuys, CA 91406 USA
(800) 222-4685
Printed in China

The preferred method of contact for
Customer Service is through our e-mail
contact form at www.mgae.com.



Bratz™ THE MOVIE RC CRUISER

WARNING:
CHOKING HAZARD—Small parts.
Not for children under 3 years.

Ages 6+

Asst. no.: 366355

ADULT BATTERY INSTALLATION REQUIRED

INTRODUCTION

This super-cool, crusin', classic car is straight out of the Bratz™ movie! With its sizzlin' style and kickin' curves, it's the perfect ride for your Bratz™!

CONTENTS

- 1 Bratz™ The Movie RC Classic Vehicle (operated under either 27MHz or 49MHz frequency)
- 1 Remote Control

BEFORE YOU BEGIN

Before hitting the road in your classic car, ask an adult to help you to install batteries. Here's how.

REMOTE CONTROL

1. Turn the ON/OFF switch to OFF
2. Using a Phillips screwdriver (not included) remove the screw and battery compartment cover on the back of the remote. (See Fig. 1)
3. Insert a 9V ALKALINE battery (not included) making sure the (+) and (-) ends face the proper direction as indicated inside the battery compartment. (See Fig. 2)
4. Replace the compartment cover, tighten the screw and turn the ON/OFF switch to the ON position.




Fig. 1




Fig. 2

VEHICLE

1. Press the button on the vehicle trunk to open the trunk lid.
2. Turn the ON/OFF switch located inside the trunk to OFF. (See Fig. 3)
3. Using a Phillips screwdriver (not included) remove the screw and battery compartment cover from inside the trunk.
4. Install six (6) AA (1.5V) alkaline batteries (not included) making sure the (+) and (-) ends face the proper direction as indicated inside the battery compartment.
5. Replace the compartment cover, tighten the screw, turn the ON/OFF switch to ON and close the trunk.




Fig. 3




Fig. 4




Fig. 5

NOTE: When racing two Bratz™ The Movie RC vehicles, they must be of opposite radio frequencies or they may not perform as designed.