User Guide

Note: Your phone is fully functional without the flip. It will act as if the flip is open.

# Auto Answer For The Hands-Free Car Kit

While your phone is connected to your Sprint PCS Hands-Free Car Kit you can set your phone to auto answer. This feature will enable your phone to answer incoming calls automatically after 5 seconds; you do not have to press anything. (WARNING: While your phone is in the Auto Answer mode your phone will answer incoming calls regardless of whether you are present or not.) To activate this feature:

- 1. From the menu, highlight Setup and press OK
- 2. Highlight Car Use and press OK.
- 3. Highlight Auto Answer and press OK.
- 4. Highlight and press OK

To disable Auto Answer, simply follow steps 1 - 3 and select Off.

#### **Any Key Answer**

Your phone can be set to answer incoming calls by pressing any key (Not including the **CLR** key, mouse key, or volume keys). To customize your phone to function this way, follow these simple instructions:

- 1. From the menu, highlight Setup and press OK
- 2. Highlight Any Key Answer and press OK
- 3. Highlight on and press OK.

# Accessories

A variety of accessories are available for your new Sprint PCS Touchpoint<sup>TM</sup> phone. You can choose the accessories that best meet your personal communication needs. Accessories can be ordered by calling the Sprint PCS Accessories Hotline<sup>SM</sup> (1-800-974-2221) or **# A C C** from your Sprint PCS Touchpoint<sup>TM</sup> phone.

#### Cigarette Lighter Adapter

You can operate your Sprint PCS Touchpoint<sup>TM</sup> phone and charge the phone's battery from your vehicle by using the Cigarette Lighter Adapter. If your battery's charge is completely run down, it will take approximately two to three hours to recharge

#### Hands-Free Car Kit

The Hands-Free Car Kit enables you to attach the phone to your car, providing you with hands-free operation as well as charging your phone's battery. If your battery's charge is completely run down, it will take approximately two to three hours to recharge.

# Standard Battery

The standard battery gives you approximately three hours of talk time or 48 hours of standby time. Talk and standby time may vary with user settings. Turning the backlight to OFF will give you maximum battery life.


#### **Extended Battery**

The extended battery gives you approximately five hours of talk time or 72 hours of standby time. The battery charges in approximately three–four hours, using any of the charger accessories.

# **Battery Care and Storage**

For best battery performance, follow these guidelines:

- Only use Sprint PCS approved battery packs and charging devices. These chargers are designed to maximize battery life. Using other batteries or chargers will void your warranty and may cause damage as well.
- To avoid damage, charge the battery only in temperatures ranging from 32°F to 130°F.
- Do not use the battery charger in direct sunlight or in high humidity areas, such as the bathroom.
- Never dispose of the battery pack by burning.
- Keep the metal contacts at the top of the battery pack clean.
- Do not allow the battery contacts to touch metal materials.
- Do not attempt to disassemble or short-circuit the battery pack.
- Do not use battery if visibly damaged
- Keep the battery out of the reach of children or pets.
- You may need to recharge the battery if it has not been used for a long time.



#### **Disposal of Batteries**

The Sprint PCS Touchpoint<sup>TM</sup> batteries are Lithium Ion (Li-Ion); please dispose of properly.

Note: In some areas, the disposal of rechargeable batteries in household or business trash may be prohibited.

#### **Desktop Charger**

The two-slot desktop charger provides a means for charging the phone and a spare battery at the same time. It consists of an AC/DC adapter, which provides the required DC power to a two-slot phone/battery cradle and charges a standard battery in approximately two hours, and the extended battery in approximately three hours.

The desktop charger also has a dual color LED for each slot. The lights will illuminate red when the battery and/or phone is charging and green when the battery and/or phone is fully charged.

# Subscriber Information Manager (SIM-100) Software

The SIM-100 Software is a PC-windows based application used to manage your internal phone book, scheduler appointments and alarms, and user preferences of the Sprint PCS Touchpoint<sup>TM</sup> phone. This enables you to input your phone book and scheduler data directly into your PC and download that information from your PC to your Sprint PCS Touchpoint<sup>TM</sup> phone.