

<b>Consumer Use Modes</b>	<b>Service Mode</b>	<b>Mode of Operation</b>	<b>Explanation</b>	<b>Frequency of Transmission</b>
X		Park Mode	All of the time other than other modes	No transmission
X		Drive Mode	TPM sensor in normal operation when vehicle motion is detected	10 words every 32 seconds
	X	Learn Mode	TPM sensor transmits up to 35 words after LF tool activation	Up to 35 words in less than 5

**NOTES:**

- 1.- The service mode is used only to learn the identifier of the TPM sensor in the vehicle TPM system. This mode will only be used at the tire dealers/service centers only.
- 2.- The power level for all transmissions is the same.