



## HR4 (G03302) & HR5 (G03303) Antenna – Construction and Location



**HR4 / HR5 Smart Reader**



**Antenna (ø 0.5mm wire with 63 turns) located at the tip inside the snout**



**Non-Detachable Snout**