


PHOTOGRAPH 13
FCC ID: M7QAV-SENDER
SOLDER VIEW OF THE ADAPTOR




PHOTOGRAPH 12
FCC ID: M7QAV-SENDER
COMPONENT VIEW OF THE ADAPTOR


FCC ID: M7QAV-SENDER

PHOTOGRAPH 11

INTERNAL VIEW OF THE ADAPTOR




PHOTOGRAPH 08
FCC ID: M7QAV-SENDER
SOLDER VIEW OF RF MODULE




FCC ID: M7QAV-SENDER

PHOTOGRAPH 07

COMPONENT VIEW OF RF MODULE






FCC ID: M7QAV-SENDER


PHOTOGRAPH 06


SOLDER VIEW OF MAIN BOARD



PHOTOGRAPH 05
FCC ID: M7QAV-SENDER
COMPONENT VIEW OF MAIN BOARD

INTERNAL VIEW OF THE EUI





PHOTOGRAPH 03
FCC ID: M7QAV-SENDER
INTERNAL VIEW OF THE EUT