


Left Antenna Next to Left Display Hinge

BT Antenna

Connectors of Rear Panel




BT Module

View Shown is from Lap or Bottom Side

Left Antenna

Left Antenna Connector

Display



Display Hinge

Display Hinge & Right
Antenna Location