

1. The Universal Transmitters can be used for a number of function. The most popular is protection of doors and windows; however, the unit can be connected to a panic switch and by setting all Zone code Switches to OFF, the Panic Zone can be activated. This is ideal as a fixed Wireless Panic Alarm.
2. The detector connected with the transmitter should be N/C type (normal close). Or momentary N/O (normal open) type.