


PRODUCT LABELING



Marking: Black printing
Character size and location to be adjusted according to label size

Stick the label on the rear cabinet in the dedicated label location

Part Number structure :
P/N : HWP118184 +V (example HWP118184B)
V = letter of version of the product (example B)



Serial Number structure :
B/N : YAAMLLCCCC (example I003020883)
Y = subcontractor code (example I for MIGHT)
AA = manufacturing year (example 00 for year 2000)
M = manufacturing month in alphanumeric character, from 1 to C (example 3 for March)
LL = batch number within the month (example 02, second batch of the current month)
CCCC = Baseline Number (This information is provided with the "DIDO")

Bar Code Area: AAMXXXXX followed by Code 128 print
AA = manufacturing year (example 00 for year 2000)
M = manufacturing month in alphanumeric character, from 1 to C (example 3 for March)
XXXXX = incremental serial number on 5 digits (example 00001~10000)