

XR15 Voice Remote Control



1 Turn on your remote

Your remote arrives with the AA batteries already installed, but not activated. Here is how to power it on for the first time.

1. Pick up your remote and remove the **"Pull" tab** (on back) by **pulling away** from the remote. The Status LED will **blink green** four times as the remote powers up (about 5 seconds).
2. Turn on your **TV**.
3. Turn on your **set-top box**.

2 Pair Your Remote for Voice Control

Use voice control to search for networks and shows, set DVR recordings, and get recommendations. See **Step 5** of this guide for examples.

1. Press and hold the **Xfinity** and **Info** buttons (about 5 seconds) until the Status LED changes from **red to green**.

3 Control Your TV's Power and Volume

Control the power, volume, and input of your TV using your Xfinity Remote.

1. Find the **5-digit code** for your TV manufacturer.
2. Press and hold the **Xfinity** and **Info** buttons (about 5 seconds) until the Status LED changes from **red to green**.
3. Enter the **first** 5-digit code for your TV manufacturer. The Status LED should **flash green twice**.
4. Verify that the code was accepted by using your remote to adjust **volume** and turn the TV **on and off**.

4 Test Voice Control

Once your remote is paired with your set-top box, you can use voice control.

1. Press and hold the **Voice button** until you hear the audio tone.
2. **Speak a voice command** to the remote while continuing to hold down the button. The Status LED will be **solid blue** while you speak your command.
3. Release the **Voice button** when your command is complete. Look at the TV for the results of your voice command.

FCC Compliance Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not used in accordance with the instructions, may cause harmful interference to radio communications.

There is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase or decrease the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that which the receiver is connected.
- Consult the dealer or an experienced remote control / TV technician for help.
- It is strongly recommended that the TV be plugged into a separate wall outlet.

The user is cautioned that changes and modifications made to this equipment without the approval of the manufacturer could void the user's authority to operate this equipment.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.