



Radiated Emissions Test Configuration (ST2 Remote Control Transmitter)




Radiated Emissions Test Configuration (ST2 Remote Control Transmitter)






Radiated Emissions Test Configuration (ST2 Remote Control Charger)



Radiated Emissions Test Configuration (ST2 Remote Control Charger)





Line Conducted Emissions Test Configuration (ST2 Remote Control Charger)



Line Conducted Emissions Test Configuration (ST2 Remote Control Charger)