

INSTRUCTIONS

The immobilizer is a theft prevention system. When you insert the Key in the cylinder, the transponder chip built in the key's head transmits an electronic code to the vehicle. The vehicle allows the engine to start, only when the electronic code is identified.

For vehicles sold in U.S.A.:

NOTE

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC WARNING

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

For vehicles sold in Canada:

NOTE

Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.