

TPMS (Tire Pressure Monitoring Sensor)

Model AG2PF4

User Manual

Schrader Sensor Overview

The Schrader Electronics TPMS (Tire Pressure Monitoring) Sensor is designed to be used in a direct measurement TPM System. The TPM Sensor is intended to interface to a receiver/decoder that has been designed to accept the TPM sensor protocol.

The TPM Sensor is designed to monitor a vehicle's tyre pressure whilst driving or stationary. An electronic unit inside each tyre (referred to as the TPM Sensor or TPM transmitter) mounted to the valve stem, periodically measures actual tyre pressure/temperature.

This pressure information is transmitted to a receiver/decoder by means of an RF link. The incoming radio frequency signals are decoded, and the data used to inform the driver of the tyre pressure information via the vehicles TPM interface.

TPM Sensor main functions are:

- Regularly measure the tyre pressure.
- Monitor if the wheel is moving.
- Periodically transmit tyre pressure using an RF link and a specific protocol.
- Notify the system if there are abnormal pressure variations (leak) in the tyre.
- Monitor the transponder input for valid LF field



Schrader Electronics Ltd
Unit 11 Technology Park
Belfast Road
Antrim, Northern Ireland, BT41 1QS

FCC ID: MRXAG2FP4

IC: 2546A-AG2FP4

This device complies with Part 15 of the FCC Rules
Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- 1) L'appareil ne doit pas produire de brouillage;
- 2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body

Déclaration d'exposition aux radiations:

Cet équipement est conforme aux limites d'exposition aux rayonnements ISED établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé à plus de 20cm entre le radiateur et votre corps.

The World Depends on Sensors and Controls

http://www.tpmseuroshop.com/documents/declaration_conformities