



SCHRADER ELECTRONICS.LTD..
TMS TRUCK LASER WELD 433 MHZ

Product Specification.

The TPMS Transmitter is installed to each tyre of a vehicle. The unit measures tyre pressure periodically and transmits this information by RF communication to a receiver inside the vehicle. In addition, the TPMS Transmitter performs the following functions:

- Determines a pressure value.
- Determines any abnormal pressure variations in the wheel.
- Monitors the state of the Transmitters' internal battery and informs the receiver of a low battery condition.