





802.11ax (20MHz) 6475MHz Chain C NSS-4

802.11ax (20MHz) 6475MHz Chain D NSS-4










802.11ax (20MHz) 6515MHz Chain A NSS-4



802.11ax (20MHz) 6515MHz Chain B NSS-4



802.11ax (20MHz) 6515MHz Chain C NSS-4



802.11ax (20MHz) 6515MHz Chain D NSS-4







802.11ax (20MHz) 6695MHz Chain C NSS-4

802.11ax (20MHz) 6695MHz Chain D NSS-4





802.11ax (20MHz) 6855MHz Chain A NSS-4

802.11ax (20MHz) 6855MHz Chain B NSS-4





802.11ax (20MHz) 6855MHz Chain C NSS-4

802.11ax (20MHz) 6855MHz Chain D NSS-4





802.11ax (20MHz) 6875MHz Chain A NSS-4

802.11ax (20MHz) 6875MHz Chain B NSS-4





802.11ax (20MHz) 6875MHz Chain C NSS-4

802.11ax (20MHz) 6875MHz Chain D NSS-4





802.11ax (20MHz) 6895MHz Chain A NSS-4

802.11ax (20MHz) 6895MHz Chain B NSS-4





802.11ax (20MHz) 6895MHz Chain C NSS-4

802.11ax (20MHz) 6895MHz Chain D NSS-4



802.11ax (20MHz) 7015MHz Chain A NSS-4

802.11ax (20MHz) 7015MHz Chain B NSS-4



802.11ax (20MHz) 7015MHz Chain C NSS-4

802.11ax (20MHz) 7015MHz Chain D NSS-4

