





802.11ax (160MHz) 6505MHz Chain A NSS-1

802.11ax (160MHz) 6505MHz Chain B NSS-1









802.11ax (160MHz) 6505MHz Chain C NSS-1

802.11ax (160MHz) 6505MHz Chain D NSS-1





802.11ax (160MHz) 6665MHz Chain A NSS-1

802.11ax (160MHz) 6665MHz Chain B NSS-1





802.11ax (160MHz) 6825MHz Chain C NSS-1

802.11ax (160MHz) 6825MHz Chain D NSS-1




802.11ax (160MHz) 6985MHz Chain A NSS-1



802.11ax (160MHz) 6985MHz Chain B NSS-1



802.11ax (160MHz) 6985MHz Chain C NSS-1



802.11ax (160MHz) 6985MHz Chain D NSS-1







802.11ax (20MHz) 6255MHz Chain C NSS-4

802.11ax (20MHz) 6255MHz Chain D NSS-4





802.11ax (20MHz) 6415MHz Chain A NSS-4

802.11ax (20MHz) 6415MHz Chain B NSS-4




802.11ax (20MHz) 6415MHz Chain C NSS-4


802.11ax (20MHz) 6415MHz Chain D NSS-4




802.11ax (20MHz) 6435MHz Chain A NSS-4




802.11ax (20MHz) 6435MHz Chain B NSS-4



802.11ax (20MHz) 6435MHz Chain C NSS-4



802.11ax (20MHz) 6435MHz Chain D NSS-4



802.11ax (20MHz) 6475MHz Chain A NSS-4

802.11ax (20MHz) 6475MHz Chain B NSS-4