





802.11ax (80MHz) 6545MHz Chain A NSS-1

802.11ax (80MHz) 6545MHz Chain B NSS-1









802.11ax (80MHz) 6545MHz Chain C NSS-1

802.11ax (80MHz) 6545MHz Chain D NSS-1





802.11ax (80MHz) 6625MHz Chain A NSS-1

802.11ax (80MHz) 6625MHz Chain B NSS-1





802.11ax (80MHz) 6705MHz Chain C NSS-1

802.11ax (80MHz) 6705MHz Chain D NSS-1





802.11ax (80MHz) 6785MHz Chain A NSS-1

802.11ax (80MHz) 6785MHz Chain B NSS-1





802.11ax (80MHz) 6785MHz Chain C NSS-1

802.11ax (80MHz) 6785MHz Chain D NSS-1





802.11ax (80MHz) 6865MHz Chain A NSS-1

802.11ax (80MHz) 6865MHz Chain B NSS-1





802.11ax (80MHz) 6865MHz Chain C NSS-1

802.11ax (80MHz) 6865MHz Chain D NSS-1





802.11ax (80MHz) 6945MHz Chain A NSS-1

802.11ax (80MHz) 6945MHz Chain B NSS-1





802.11ax (80MHz) 6945MHz Chain C NSS-1

802.11ax (80MHz) 6945MHz Chain D NSS-1





802.11ax (80MHz) 7025MHz Chain A NSS-1

802.11ax (80MHz) 7025MHz Chain B NSS-1





802.11ax (80MHz) 7025MHz Chain C NSS-1

802.11ax (80MHz) 7025MHz Chain D NSS-1





802.11ax (160MHz) 6185MHz Chain A NSS-1

802.11ax (160MHz) 6185MHz Chain B NSS-1





802.11ax (160MHz) 6185MHz Chain C NSS-1

802.11ax (160MHz) 6185MHz Chain D NSS-1



802.11ax (160MHz) 6345MHz Chain A NSS-1

802.11ax (160MHz) 6345MHz Chain B NSS-1



802.11ax (160MHz) 6345MHz Chain C NSS-1

802.11ax (160MHz) 6345MHz Chain D NSS-1