





802.11ax (20MHz) 6535MHz Chain A NSS-1

802.11ax (20MHz) 6535MHz Chain B NSS-1









802.11ax (20MHz) 6535MHz Chain C NSS-1

802.11ax (20MHz) 6535MHz Chain D NSS-1









802.11ax (20MHz) 6695MHz Chain A NSS-1

802.11ax (20MHz) 6695MHz Chain B NSS-1





802.11ax (20MHz) 6855MHz Chain C NSS-1

802.11ax (20MHz) 6855MHz Chain D NSS-1





802.11ax (20MHz) 6895MHz Chain A NSS-1

802.11ax (20MHz) 6895MHz Chain B NSS-1





802.11ax (20MHz) 6895MHz Chain C NSS-1

802.11ax (20MHz) 6895MHz Chain D NSS-1









802.11ax (20MHz) 7015MHz Chain A NSS-1

802.11ax (20MHz) 7015MHz Chain B NSS-1





802.11ax (20MHz) 7015MHz Chain C NSS-1

802.11ax (20MHz) 7015MHz Chain D NSS-1





802.11ax (40MHz) 6125MHz Chain A NSS-1

802.11ax (40MHz) 6125MHz Chain B NSS-1





802.11ax (40MHz) 6125MHz Chain C NSS-1

802.11ax (40MHz) 6125MHz Chain D NSS-1



802.11ax (40MHz) 6245MHz Chain A NSS-1

802.11ax (40MHz) 6245MHz Chain B NSS-1



802.11ax (40MHz) 6245MHz Chain C NSS-1

802.11ax (40MHz) 6245MHz Chain D NSS-1